


Assembly

 Disconnect the power before installation.


One Way Switch




① Touch to the button with screwdriver



② Push the mechanism and remove the cover as shown in the picture



③ Place the connections and tighten the screws



④ Mount to the wall with fixation screws




Backside appearance of the product


Schuko Socket Outlet



① Remove the cover with screwdriver



② Place the connections and tighten the screws



③ Mount to the wall with fixation screws



Backside appearance of the product